

1. Plug the 3G dongle into USB port , go to “NETWORK SETTING” interface



2. Enter into “NETWORK SETTING” , Choose “3G NETWORK” at “NETWORK CONFIG” item, then the 3G will work.



Example of some compatible devices. There are others also.

Producer	Model	VID	PID
Huawei	E303(new)	0x12d1	0x1001
Huawei	E3131	0x12d1	0x1001
Huawei	E1750	0x12d1	0x1001
Huawei	E173	0x12d1	0x1001
Huawei	E153	0x12d1	0x1001
Huawei	E156G (old dongle)	0x12d1	0x1003
Huawei	E177	0x12d1	0x1001
Huawei	E1752C	0x12d1	0x1001
ZTE	MF190		
Longcheer	LS100		